

# MAXIM Assembly Instruction For 21479WGPN

1. Put the glass(F) to the frame(G)
2. Through the nipple(B) to the cap(E), glass(F) and frame(E), then secured by finial(J) till tighten
3. Insert the bulb(A) into socket
4. Hang the crystal string (D) to the metal ring(I)
5. Hang the crystal string (C) to the metal ring(H)

